

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No. L-6800-4
--

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Kimbark Oil & Gas Company	8. Farm or Lease Name New Mexico 1-4 State Com
3. Address of Operator 1580 Lincoln Street, #700, Denver, CO 80203	9. Well No. 1
4. Location of Well UNIT LETTER N 3350 FEET FROM THE South LINE AND 2310 FEET FROM West THE LINE, SECTION 4 TOWNSHIP 16S RANGE 35E NMPM.	10. Field and Pool, or Wildcat Townsend Devonian
15. Elevation (Show whether DF, RT, GR, etc.) GL 4021'; 4037' KB	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Pull rods, pump and tbg.
Set CIBP on wireline at 12,800'.
Dump 2 sx cmt on top of CIBP
Cut off and recover 5 1/2" csg as deep as possible, approx 6,500'.
Set 50 sx cmt plug in and out of csg stub.
Set 50 sx cmt plug in and out of base of intermediate csg.
Cut off intermediate and surf csg.
Set 20 sx cmt plug at surface.
Install 4' dry hole marker.
Clean and level location.
Rehabilitate surface per lessor's specifications.

100' PLUG AT 1500'

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Car. L. Anderson TITLE Operations Manager DATE August 22, 1984

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON DISTRICT SUPERVISOR TITLE DATE SEP 4 1984

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 4 1994

U.S. DEPT.
HOMER OMORI