

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-31072
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-3159
7. Lease Name or Unit Agreement Name State 10
8. Well No. 1
9. Pool name or Wildcat Sombrero <i>Marrow Gas</i>
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator Samedan Oil Corporation
3. Address of Operator 10 Desta Drive, Suite 240 East, Midland, Texas 79705
4. Well Location Unit Letter <u>G</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>10</u> Township <u>16S</u> Range <u>33E</u> NMPM <u>Lea</u> County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 5 sx plug @ 11,230 + on top of existing CIBP w/20' cmt cap.
- Set 35 sx plug @ 10,000'.
- Pull stretch & calculate free point on 5½" csg & cut at deepest possible depth
TOC = 7976'
- Set 45 sx plug 50' in & 50' out of 5½ stub.
- Cut 8 5/8 csg @ 1400 + . TOC @ 1420'.
- Set 45 sx plug 50' in & 50' out of 8 5/8 stub.
- Set 65 sx plug @ 450'-350'.
- Dump 10 sx surf plug.

100' plug top Abrieta 5700'
100' plug base salt

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Judy Throneberry TITLE Division Production Clerk DATE 3/31/93
TYPE OR PRINT NAME Judy Throneberry

TELEPHONE NO. 915-684-8491

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY: _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

APR 06 1993