

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL API NO. 30025-35635
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name: Big D State
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/> Injection <input type="checkbox"/>	7. Well No. 1	
2. Name of Operator Concho Oil & Gas Corp.	8. Pool name or Wildcat Morrow Strawn	
3. Address of Operator 110 W. Louisiana Ste 410; Midland, Tx 79701		
4. Well Location Unit Letter 11 : 3498 Feet from the North line and 1200 feet from the East line Section 6 Township 16S Range 34E NMPM Lea County		
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 4164GR		

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Concho Oil & Gas Corp. received verbal approval to plug & abandon the Big D State #1 well according to the following procedure w/ mud between all plugs:

1. Set 100' or 25 sx plug @ 12600-12500'.
2. Set 100' or 25 sx plug @ 10925-10825'.
3. Set 100' or 25 sx plug @ 7965-7865'.
4. Set 100' or 25 sx plug @ 5960-5860'.
5. Set 100' or 25 sx plug @ 4579-4479'. Tag.
6. Set 100' or 25 sx plug @ 1580-1480'.
7. Set 100' or 25 sx plug @ 453-353'. Tag.
8. Set 10 sx surface plug. Cut off wellhead. Weld on plate. Install P&A marker.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terri Stathem TITLE Production Analyst DATE 3-6-02

Type or print name Terri Stathem Telephone No. 915/683-7443

(This space for State use)

APPROVED BY _____ TITLE _____ DATE MAR 10 2002