

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE  
(Other instructions on reverse side)

EXPIRATION DATE: 1001  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐  
2. NAME OF OPERATOR  
Grauten & Pepper  
3. ADDRESS OF OPERATOR  
c/o Oil Reports & Gas Services, Inc, Box 755, Hobbs, NM 88241  
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below)  
At surface  
2310' FSL & 2117' FWL of Sec 33  
14. PERMIT NO.  
15. ELEVATIONS (Show whether DE, RE, GR, etc.)

5. LEASE DESIGNATION AND SERIAL  
NM-04242  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Denius Federal  
9. WELL NO.  
10  
10. FIELD AND POOL OR WILDCAT  
Maljamar GB/SA  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec 33 T17S R33E  
12. COUNTY OR PARISH  
Lea  
13. STATE  
NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF  
FRACTURE TREAT  
SHOOT OR ACIDIZE  
REPAIR WELL  
(Other)  
PULL OR ALTER CASING  
MULTIPLE COMPLETION  
ABANDON\*  
CHANGE PLANT

X

SUBSEQUENT REPORT OF:

WATER SHUT OFF  
FRACTURE TREATMENT  
SHOOTING OR ACIDIZING  
(Other)  
REPAIRING WELL  
ALTERING CASING  
ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATION: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to Plug & Abandon as follows:

1. Load hole with 9# per gallon mud.
2. Spot sufficient cement to provide at least 100' fill from 4575 to 4675 with at least 25 sacks. Tag plug.
3. Cut 4 1/2" casing at 1500' & pull.
4. Spot sufficient cement to provide 150' across 4 1/2" casing stub to extent 50' above casing stub. Tag plug.
5. Spot 100' cement across 11 3/4" casing shoe to extent 50' up into 11 3/4" casing. Tag plug.
6. Cement 50' surface plug.
7. Weld or cement 4" x 4' surface marker.

Notify BLM at 505-887-3612 at least 24 hours before plugging

18. I hereby certify that the foregoing is true and correct

SIGNED

Shannon J. Shaw

FOR: Donna Holler  
TITLE

Agent

DATE

5/7/90

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

8/27/90

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side