

DISTRICT I
P. O. Box 1980, Hobbs, NM 88240

DISTRICT II
P. O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P. O. Box 2088
Santa Fe, NM 87504-2088

WELL API NO. 30-025-01512
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-2148
7. Lease Name or Unit Agreement Name Caprock Maljamar Unit
8. Well No. 86
9. Pool name or Wildcat Maljamar Grayburg San Andres

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Water Injection Well	
2. Name of Operator The Wiser Oil Company	
3. Address of Operator P.O. Box 2568 Hobbs, New Mexico (505) 392-9797	
4. Well Location Unit Letter <u>N</u> : <u>660</u> Feet From The <u>South</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>21</u> Township <u>17S</u> Range <u>33E</u> NMPM <u>Lea</u> County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4173'	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Wiser requests approval to plug and abandon the well by the procedure listed below.

1. POH w/production equipment. TIH w/CIBP & set @ 4180'. Current perforations @ 4220'-4438'.
2. Dump 25 sks. cmt. on CIBP. Tag cmt. plug.
3. Circulate abandonment mud.
4. Perforate casing @ 1375' & circulate cmt. to surface. Set 25 sks. cmt. plug @ ~~307'~~ 307' (357-257) + TAG
5. Set 10 sks. cmt. @ 50' from surface.
6. Install dry hole marker & clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE M. Jones TITLE Production Superintendent DATE August 21, 2000

TYPE OR PRINT NAME Mike Jones TELEPHONE NO. (505) 392-9797

APPROVED BY _____ TITLE _____ DATE _____