

NO. OF COPIES RECEIVED

DISTRIBUTION

SANTA FE

FILE

U.S.G.S.

LAND OFFICE

OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease

State ☒Fee ☐

5. State Oil & Gas Lease No.

E-1816

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Wolfson Oil Co.		8. Farm or Lease Name Lea # State
3. Address of Operator 3206 Republic Bank Tower Dallas, Texas		9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>330</u> FEET FROM THE <u>East</u> LINE AND <u>2352</u> FEET FROM THE <u>North</u> LINE, SECTION <u>3</u> TOWNSHIP <u>17 S</u> RANGE <u>34E</u> NMPM.		10. Field and Pool, or Wildcat Vacuum (G-SA)
15. Elevation (Show whether DF, RT, GR, etc.) 4057 GR		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set 5 1/2" plug at 4645 and cap with 35' of cement.

Run tubing to 4600 feet and circulate with 9.6# mud laden fluid using 25 sacks of mud per 100 barrels of water.

Pull 5 1/2" casing,

Pump 35 sack cement plug in and out of casing stub.

Pump 35 sx plug at top of salt section

Pump 35 sx plug at base of surface pipe at 351'.

Spot 10sx surface plug

Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.G. FreedmanTITLE Prod. Engr.DATE 11-11-73

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: