

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

AUG 19 11 41 AM '65

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-9263</b>	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>The Atlantic Refining Company</b>		8. Farm or Lease Name <b>State "AJ"</b>
3. Address of Operator <b>P. O. Box 1978, Roswell, New Mexico</b>		9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>B</b> <b>330</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>17</b> TOWNSHIP <b>18-S</b> RANGE <b>34-E</b> NM 2M.		10. Field and Pool, or Wildcat <b>EK-Queen</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4071' RKE</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was temporarily abandoned in 1962. We now propose to salvage 5-1/2" casing and plug and abandon the well as follows:

1. Set 15 sx cement in 5-1/2" casing from 4369-4469.
2. Shoot off and recover 5-1/2" casing as deep as possible. (Estimated top of cement is 2000'.)
3. Set 25 sk cement plug 1/2 in and out of 5-1/2" stub.
4. Set 25 sk cement plug across anhydrite (top at 1800') if this is above 5-1/2" stub.
5. Set 25 sk cement plug in and out of 8-5/8" casing at 336'.
6. 10 sx of cement in top of well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>Ch. D. Smith</i></u>	TITLE <b>District Drilling Supervisor</b>	DATE <b>8-18-65</b>
APPROVED BY _____	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		