

COPIES RECEIVED		
DISTRIBUTION		
DATE		
BY		
OFFICE		
REPORT		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1579
7. Unit Agreement Name
8. Farm or Lease Name Los State "ID"
9. Well No. 1
10. Field and Pool, or Wildcat EX Queen East
12. County Los

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER <input type="checkbox"/>
Name of Operator Gulf Oil Corporation		
Address of Operator Box 670, Hobbs, New Mexico		
Location of Well UNIT LETTER I , 1980 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 28 TOWNSHIP 18-S RANGE 34-E NMPM.		

15. Elevation (Show whether DF, RT, GR, etc.)

4018' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

CORRECTED FORM

Form C-103 dated March 3, 1965 was incorrect. Well will be plugged and abandoned as follows:

Pull rods and pump. Spot 25 sack cement plug from bottom and across perforations 4840-4850'. Load hole with mud and pull tubing. Shoot 4-1/2" casing off at 1770' or above and pull casing. Run tubing and spot 25 sack cement plug (minimum of 50' in casing and 50' above) across casing stub. Spot 25 sack cement plug at surface. Clean location, remove all production equipment and install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE **Area Production Manager** DATE **March 8, 1965**

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: