

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

O+2 - NMOCD-P.O. Box 1980 1 - Foreman
Hobbs, NM 88240 Ed Fowler
1 - Engr. PWS 1 - File
1 - Laura Richardson-Midland

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	For <input type="checkbox"/>
5. State Oil & Gas Lease No. E-7653	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Getty Oil Company		8. Farm or Lease Name State AN
3. Address of Operator P.O. Box 730 Hobbs, NM- 88240		9. Well No. 6
4. Location of Well UNIT LETTER <u>O</u> <u>990</u> FEET FROM THE <u>South</u> LINE AND <u>2310</u> FEET FROM THE <u>East</u> LINE, SECTION <u>7</u> TOWNSHIP <u>18S</u> RANGE <u>35E</u> NMPM.		10. Field and Pool, or Wildcat Vacuum Abo, Reef
15. Elevation (Show whether DF, RT, GR, etc.) 3972' DF		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Clean out, reperforate and acidize</u> <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up unit.
2. Install BOP.
3. Pull tubing.
4. Reperforate 8850-8881. 1 shot/ft.
5. Acidize perfs 8850-8881.
6. Test perfs.
7. Squeeze perfs if necessary.
8. Reperforate 8800-8834.
9. Treat w/3500 gal. acid.
10. Swab and test.
11. If necessary, re-acidize.
12. Place back on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Area Superintendent DATE November 8, 1982

ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE NOV 10 1982

CONDITIONS OF APPROVAL