

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>E-1635</b>

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Sinclair Oil &amp; Gas Company</b>	8. Farm or Lease Name <b>State Lea 405</b>
3. Address of Operator <b>P.O. Box 1920, Hobbs, New Mexico</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>EEN C</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>27</b> TOWNSHIP <b>18S</b> RANGE <b>35E</b> NMPM.	10. Field and Pool, or Well Unit <b>South Vacuum Bone Springs</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <b>Lea</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS:

Set 25 sk cement plug over Bone Spring perforations 8649-8681.  
Set 25 sk cement plug in top of 7" CD Casing stub (will cut off and recover as much 7" cd casing as possible above top of cement behind 7" esg which is 8090' from surface)  
Set 25 sk cement plug at 6900' (top of Bone Springs)  
Set 25 sk cement plug at 5950' (base of San Andres)  
Set 25 sk cement plug at 4990' (bottom of 9-5/8" cd casing).  
Set 10 sk cement plug at surface.  
Set regulation marker and clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE **Superintendent** DATE **6-21-65**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: