

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

JUN 30 11 35 AM '66

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.
-

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Shell Oil Company (Western Division)	8. Farm or Lease Name Rice
3. Address of Operator P. O. Box 1509, Midland, Texas 79701	9. Well No. 3
4. Location of Well UNIT LETTER <u>I</u> , <u>1650</u> FEET FROM THE <u>south</u> LINE AND <u>990</u> FEET FROM THE <u>east</u> LINE, SECTION <u>13</u> TOWNSHIP <u>18S</u> RANGE <u>37E</u> NMPM.	10. Field and Pool, or Wildcat Hobbs
15. Elevation (Show whether DF, RT, GR, etc.) 3676' DF	12. County Lea

### 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input checked="" type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>	PLUG AND ABANDONMENT	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>		<input type="checkbox"/>
OTHER	<input type="checkbox"/>		<input type="checkbox"/>

### 17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods, pump and tubing.
2. Run 2-60'-1000 grain shots over open hole interval 4020' - 4080'.
3. Check for fill and clean out.
4. Run tubing and treat open hole w/2000 gallons 28% NEA & overflush w/2000 gallons fresh water.
5. Run production equipment and place on production.

### 18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. D. Duren J. D. Duren TITLE Staff Exploitation Engineer DATE June 29, 1966

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: