

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

3-NMOCC
1-File

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name W. D. Grimes
9. Well No. 1
10. Field and Pool, or Wildcat Bowers, 7 Rivers
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator GETTY OIL COMPANY
3. Address of Operator P. O. Box 249, Hobbs, New Mexico
4. Location of Well UNIT LETTER I , 1650 FEET FROM THE South LINE AND 990 FEET FROM THE East LINE, SECTION 29 TOWNSHIP 18S RANGE 38E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 1103.

Well has been NIO since March 1, 1958. An attempt in 1966 to recompleate as a Byers gas well was unsuccessful. We propose to plug and abandon as follows:

Lay 25 sack cement plug at 3500'
Lay 25 sack cement plug at top of 7" stub
Lay 25 sack cement plug at top of 9-5/8" stub
Lay 25 sack cement plug in and out bottom of 12-1/2" casing
Lay 10 sack cement plug at surface

Install dry hole marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By

C. L. WADE

TITLE **Area Superintendent**

DATE **4-1-68**

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: