

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN ORIGINAL OR COPY
(SEE INSTRUCTIONS ON REVERSE SIDE)Form approved,
Budget Bureau No. 42 R142
5. LEASE DESIGNATION AND SERIAL NO.
LC 032241-60
6. IS INDIAN, ALLOTTEE OR TRIBE NAME

SUNDY NOTICES AND REPORTS ON WELLS

(Do not use this form for notices to drill, plug, abandon or shut back to a different reservoir.
USE APPLICATION FOR PLUGGING for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR <i>Humble Oil & Refining Co.</i>	8. FARM OR LEASE NAME <i>Howers A Federal</i>
3. ADDRESS OF OPERATOR <i>Box 1600, Midland, Texas</i>	9. WELL NO. <i>16</i>
4. LOCATION OF WELL. (Set location clearly and in accordance with any State requirements.* (See also space 17 below.) At surface <i>660 FSL, 1980 FFL</i>	10. FIELD AND POOL, OR WILDCAT <i>Powers T Rivers</i>
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR ALIA <i>S30, T18S, R38E</i>
15. ELEVATIONS (Show well head, ft., or, etc.) <i>5052 DF</i>	12. COUNTY OF PLAINSH <i>Leah</i>
	13. STATE <i>W. Va.</i>

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐FULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recordation Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.*

Permission is requested to plug and abandon well as follows:

1. Set cement plug from 3050-3225' w/ 25 sack cement.
2. Set cement plug from 50'- surface w/ 10 sack cement.
3. Install dry hole marker and clean location.
4. Mud laden fluid between plugs.

ADDITIONAL: Set additional 21-sack cement plug at 1400-1550 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED *William H. Hurd*TITLE *Unit Head*DATE *1/17/70*

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side