

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	N. HOBBS (G/SA) UNIT
3. Address of Operator	8. Farm or Lease Name
P. O. BOX 991, HOUSTON, TX 77001	SECTION 32
4. Location of Well	9. Well No.
UNIT LETTER B 990 FEET FROM THE NORTH LINE AND 2310 FEET FROM THE EAST LINE, SECTION 32 TOWNSHIP 18-S RANGE 38-E NMPM.	10. Field and Pool, or Wildcat
	HOBBS (G/SA)
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3638' GR	LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data.

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Displace hole with mud laden fluid.
2. Spot Class "C" neat cement plugs as follows:
 - a) Spot 100' plug 50' above and below the base of the salt using 15 sx of Class "C" neat from 2560' to 2460'.
 - b) Perforate @ 1580'. Open bradenhead valve on 12-1/2" casing spool and pump 1350 sx Class "C" neat cmt to surface. Close valve. Open 6-5/8" X 9-5/8" valve and pump 270 sx Class "C" neat cmt. Displace with mud laden fluid.
 - c) Spot a 10 sx Class "C" neat cmt plug from 71' to 3'.
3. Cut casing off 3' below the surface and install P&A marker.
4. Clean and level location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>A. J. FORE</u>	TITLE <u>SUPERVISOR REG. & PERMITTING</u>	DATE <u>MARCH 7, 1984</u>
ORIGINAL <u>SECTION</u>		
DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>MAR 13 1984</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED
MAR 12 1984
OCE
NOBBES OFFICE