

OF COPIES RECEIVED	
DISTRIBUTION	
ITA FE	
E	
S.G.S.	
ND OFFICE	
PERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name S. P. Johnson
9. Well No. 1
10. Field and Pool, or Wildcat Carter San Andres
12. County Lea

SUNDY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
1. Name of Operator R. G. McPHERON
3. Address of Operator Box 176, Hobbs, New Mexico
4. Location of Well UNIT LETTER <u>L</u> , <u>990</u> FEET FROM THE <u>West</u> LINE AND <u>1650</u> FEET FROM THE <u>South</u> LINE, SECTION <u>5</u> TOWNSHIP <u>18 S</u> RANGE <u>39 E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3634 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Set cement plug from 5254' to 5100', fill 7" from 5100' back to 3100' w/11# mud. Cut 7" csg. off @ 3100' and pull from hole. Set cement plug 3100'-3000', fill hole from 3000' to 2170' w/mud, set cement plug from 2170'-2070'. Fill hole from 2070' back to 330' w/mud. Set 25 sx cement from 330'-220'. Fill 9-5/8" w/mud from 220' to 25'. Fill 9-5/8" from 25' to surface w/10 sx cement and set 4" x 5' marker above ground level. Estimated starting date November 13, 1967.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>R. G. McPHERON</u>	TITLE <u>Operator</u>	DATE <u>11/10/67</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>COMMISSIONER</u>	DATE <u>NOV 13 1967</u>
CONDITIONS OF APPROVAL, IF ANY:		