

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-20160 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-6704

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name Vacuum Abo Unit Btry 1, Tract 15
2. Name of Operator Phillips Petroleum Company	8. Well No. 4
3. Address of Operator 4001 Penbrook Street, Odessa, TX 79762	9. Pool name or Wildcat Vacuum Abo Reef
4. Well Location Unit Letter <u>E</u> : <u>1650</u> Feet From The <u>North</u> Line and <u>330</u> Feet From The <u>West</u> Line Section <u>8</u> Township <u>18-S</u> Range <u>35-E</u> NMMPM <u>Lea</u> County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3971' RKB

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☒ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MI and RU DDU. COOH with rods (if applicable). Install BOP. COOH with tubing (if applicable).
- If a pressure bomb was not run previously due to rods in the hole, run in with bomb to top of perforations. Obtain 1 hour shut-in pressure. COOH.
- RIH with CIBP on workstring. Set CIBP no more than 100' above top perforation.
- Fill casing with inhibited brine, test to 500 psi, and record chart.

THIS COMPLETION MUST BE NOTIFIED  
AS REQUIRED PRIOR TO COMMENCING WORK

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE L. M. Sanders TITLE Supervisor, Reg. Affairs DATE 8/24/92  
TYPE OR PRINT NAME L. M. Sanders TELEPHONE NO. 915/368-1488

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

AUG 27 '92

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: