

UNITED STATES
DEPARTMENT OF THE INTERIOR

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT TO DRILL" for such proposals.)

NOV 19 10 12 AM '63

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ **Dry Hole**

2. NAME OF OPERATOR
Pan American Petroleum Corporation

3. ADDRESS OF OPERATOR
Box 68 - Hobbs, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
1980' FN X E Lines, Sec. 20, (Unit G, SW/4 NE/4)

5. LEASE DESIGNATION AND SERIAL NO.
062514-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
N. Featherstone-Federal

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Wildcat

11. SEC., T. R., M., OR B.L. AND SURVEY OR AREA
20-14-33 NE/4

12. COUNTY OR PARISH
Lea

13. STATE
N.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
3835' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

After further evaluation, it has been determined that no completion possibilities exist.
We propose to FIA as follows:

1. Spot 10 sz. cement plug across perforations 3014-3034.
2. Locate free point and pull 4-1/2" casing.
3. Spot 25 sz cement plug in and out 13-3/8" casing shoe at 332'.
4. Spot 10 sz. cement plug at surface and erect FIA marker.
5. Clear and level location to natural contour of the land.

SUBJECT TO:

A ten sack cement plug shall be placed across the stub of the 4 1/2" casing, after it has been cut and pulled.

18. I hereby certify that the foregoing is true and correct

SIGNED

JOHN STALEY

TITLE

Area Superintendent

DATE

11-7-63

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

*** SUBJECT TO CONDITIONS ABOVE**

NOV 12 1963

*See Instructions on Reverse Side

J. L. GORDON
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

Nov 12 10 15 AM '63

HOBBES OFFICE O.C.C.