

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B-5310</b>	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator <b>CITIES SERVICE OIL COMPANY</b>		8. Farm or Lease Name <b>Cockburn A - State</b>
3. Address of Operator <b>P. O. Box 69, Hobbs, New Mexico 88240</b>		9. Well No. <b>4</b>
4. Location of Well UNIT LETTER <b>B</b> , <b>990</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>32</b> TOWNSHIP <b>17S</b> RANGE <b>33E</b> NMPM.		10. Field and Pool, or Wildcat <b>Corbin Abo</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4064' DF</b>		12. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to perforate additional Abo zones and acidize all zones in the following manner:

1. MIRU Pulling Unit, install BOP and pull rods and tubing.
2. Perforate w/2 holes each @ 8600, 8611, 8614, and 8626.
3. Run tubing w/packer set @ 8500 and acidize all perforations (new perforations 8600-8626, old perforations 8632-8695) with 3000 gallons 15% HCL (stabilized) acid + 35 ball sealers.
4. Swab load and swab test.
5. Pull packer, run tubing, rods and pump.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED \_\_\_\_\_ TITLE **Dist. Admin. Supervisor** DATE **June 1, 1972**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE **JUN 5 1972**  
CONDITIONS OF APPROVAL, IF ANY: **Orig. Signed by Joe D. Ramey Dist. I, Supv.**