

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE
(Other instructions
verse side)

Budget Bureau No. 1004-1
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

GIL WELL ☐ GAS WELL ☒ OTHER

AUG 7 11 06 AM '91

2. NAME OF OPERATOR

Robert N. Enfield

3. ADDRESS OF OPERATOR

P. O. Box 2431, Santa Fe, NM 87504-2431

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

660' FNL and 1980' FEL Sec. 29

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3799' GR

5. LEASE DESIGNATION AND SERIAL

LC 069276

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hudson "29" Federal

9. WELL NO.

1

10. FIELD AND POOL OR WILDCAT

Corbin, S. Morrow
SEC. T, R, M, OR B, L, AND
SURVEY OR AREA

Sec. 29, T-18-S, R-33-E

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETION

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON* temp.

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(Other) Temporarily abandon

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

NOTIFY BLM AT (505)393-3612 FOR A REPRESENTATIVE TO WITNESS CSG TEST.

- 1.) Move-in and rig-up plugging equipment.
- 2.) Run and set a CIBP at 8600' KB; dump 35 feet of cement on top of plug.
- 3.) Load casing with 10# brine.
- 4.) Pressure to 500 psig for 30 minutes.
- 5.) Install surface valve.

**NOTE: This is to revise procedure to I/A at 4200' dated
March 7, 1991.

6. SUBMIT SUBSEQUENT REPORT AND THE PRESSURE TEST CHART.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

8/6/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

8/20/91

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side