

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1553	
7. Unit Agreement Name	
8. Farm or Lease Name	
State NG	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Arkansas Jct. - S.A.	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> WELL GAS <input type="checkbox"/> WELL OTHER <input type="checkbox"/>	2. Name of Operator
AZTEC OIL & GAS COMPANY	3. Address of Operator
P. O. Box 837, Hobbs, New Mexico 88240	4. Location of Well
UNIT LETTER G 1930 FEET FROM THE North LINE AND 1930 FEET FROM East LINE, SECTION 24 TOWNSHIP 18-S RANGE 36-E N.M.P.M.	15. Elevation (Show whether DF, RT, GR, etc.)
	3757 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to Plug & Abandon this well in the following manner:

1. Set 100' (25 sxs) cement plug from 5068-4968' (San Andres).
2. Load hole with 10# mud laden fluid.
3. Set 100' (25 sxs) cement plug from 4080-3980' (Queen).
4. Set 100' (25 sxs) cement plug from 3147-3047' (Yates).
5. Set 100' (25 sxs) cement plug from 2057-1957' (Salt).
6. Set 100' (25 sxs) cement plug in and out of Surface Pipe.
7. Set 10 sxs cement plug at Surface with Dry Hole Marker, Clear & Level Location.
8. If pipe is pulled, set 100' (25 sxs) cement plug in and out of Stub.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Nathan E. Olegg TITLE District Superintendent DATE Dec. 27, 1972
PROVED BY Nathan E. Olegg TITLE OIL & GAS INSPECTOR DATE DEC 29 1972
CONDITIONS OF APPROVAL, IF ANY: