

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
3496

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
AZTEC OIL & GAS COMPANY	State AJ
3. Address of Operator	9. Well No.
P. O. Box 837, Hobbs, New Mexico 88240	3
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER K, 2030 FEET FROM THE South LINE AND 1980 FEET FROM	Arkansas Jct. S.A.
THE West LINE, SECTION 1 TOWNSHIP 18-S RANGE 36-E N.M.P.M.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3798 DF	Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to Plug & Abandon this well in the following manner:

1. Set 100' (25 sxs cement plug from 5200-5100' (San Andres).
2. Load hole with 10# mud laden fluid.
3. Set 100' (25 sxs) cement plug from 4080-3980' (Queen).
4. Set 100' (25 sxs) cement plug from 3147-3047' (Yates).
5. Set 100' (25 sxs) cement plug from 2057-1957' (Salt).
6. Set 100' (25 sxs) cement plug in and out of Surface Pipe.
7. Set 10 sxs cement plug at Surface with Dry Hole Marker, Clear & Level Location.
8. If Pipe is pulled, set 100' (25 sxs) cement plug in and out of Stub.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE District Superintendent	DATE Dec. 27, 1972
APPROVED BY <i>Nathan E. Olegg</i>	TITLE OIL & GAS INSPECTOR	DATE DEC 29 1972
CONDITIONS OF APPROVAL, IF ANY:		