

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-24329
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Texaco Exploration & Production, Inc.		6. State Oil & Gas Lease No.
3. Address of Operator P. O. Box 3109, Midland, Texas 79702		7. Lease Name or Unit Agreement Name: Vacuum Grayburg San Andres Unit
4. Well Location Unit Letter <u>F</u> : <u>1390</u> feet from the <u>North</u> line and <u>2580</u> feet from the <u>West</u> line Section <u>1</u> Township <u>18S</u> Range <u>34E</u> NMPM Lea County		8. Well No. 49
10. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. Pool name or Wildcat Vacuum Grayburg

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

1. Set 4 1/2" CIBP @ 4200'. Spot 25 sx plug 4200-3900 on CIBP. TAG
2. Displace hole w/MLF 9.5# brine w/25# gel p/BBL
3. Cut 4 1/2" csg @ 2400', L/D same
4. Spot 60 sx plug 2400'-2200' (Stub, B-Salt) WOC Tag
5. Spot 60 sx plug 1300'-1100' (T-Salt) WOC Tag
6. Spot 75 sx plug 425'-250' (8 5/8" Shoe) WOC Tag
7. Spot 10 sx 10'-Surf, Install dry hole marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Poly Abalos TITLE Consultant DATE 9/19/00

Type or print name Poly ABALOS Telephone No. _____
(This space for State use)

APPROVED BY _____ TITLE _____ DATE _____
Conditions of approval, if any: