

STRICT I
O. Box 1980, Hobbs, NM 88240
STRICT II
O. Drawer DD, Artesia, NM 88210
STRICT III
O. Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-30162
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG-8600
7. Lease Name or Unit Agreement Name Tonto "23"
8. Well No. 1
9. Pool name or Wildcat North Airstrip Bone Springs

SUNDRY NOTICES AND REPORTS ON WELLS
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	Name of Operator J&G Enterprise Ltd., Co.
Address of Operator P.O. Box 100, Artesia, New Mexico 88210	Well Location Unit Letter <u>B</u> : <u>660</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>East</u> Line Section <u>23</u> Township <u>18S</u> Range <u>34E</u> NMPM Lea County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>3974 GR</u>

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

FORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
PROVINCIAL ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
OR ALTER CASING <input type="checkbox"/>	OTHER: <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER: <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Estimated top of cement 6800' Meridian Temp Survey dated 4-11-88.
1. Set CIBP @ 7000' w/35 sx cement on top.
 2. Cut 7" @ 6500' & attempt to pull. Place 35 sx plug in & out of 6500 stub.
 3. Place 35 sx plug in & out of 9-5/8" @ 3415'.
 4. Place 35 sx plug in & out of 13-3/8" @ 413'.
 5. Place 10 sx plug in top of hole.
 6. Install dry hole marker.
 7. Plan to start plugging 3-18-96.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James E. Guy TITLE Vice-President DATE 3-12-96
OR PRINT NAME James E. Guy TELEPHONE NO. 505-746-9680

space for State Use)

ORIGINAL SIGNED BY
CARY WINK
FBI DEPT II

MAR 14 1996

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: