

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Cities Service Oil Co.		5. State Oil & Gas Lease No. B-1482
3. Address of Operator P.O. Box 69 - Hobbs, New Mexico		7. Unit Agreement Name -
4. Location of Well UNIT LETTER K 2310 FEET FROM THE South LINE AND 1690 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 17S RANGE 35E NMPM.		8. Farm or Lease Name State DJ
		9. Well No. 2
		10. Field and Pool, or Wildcat Vacuum Abo Reef
15. Elevation (Show whether DF, RT, GR, etc.) 3917 DF, 3906 GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose the following remedial work:

1. Pull rods & tubing
2. Install BOP
3. Perf. w/1-3/8" hole each @ 8948, 8955, 8959, 8961, 8963, 8967 and 8970
4. Run Tubing w/packer set @ 8930
5. Acidise thru Perfs (new Perfs. 8948-8970, old perfs. 8940-47, 8949-54, 8973-79 & 8980-9000) w/5000 gals 15% x 1ST acid (Ball Sealers to spaced in first 2500 gals.)
6. Pull tubing and packer
7. Run tubing and rods and start pumping test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>C.R. Robertson</u>	TITLE <u>District Clerk</u>	DATE <u>5-17-65</u>
APPROVED BY <u>[Signature]</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		