

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p>
<p>1. CIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection</p>		<p>5. State Oil & Gas Lease No.</p>
<p>2. Name of Operator Shell Oil Company</p>		<p>7. Unit Agreement Name</p>
<p>3. Address of Operator P. O. Box 1509 - Midland, Texas 79701</p>		<p>8. Farm or Lease Name East Pearl Queen Unit</p>
<p>4. Location of Well UNIT LETTER D, 660 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 22 TOWNSHIP 19-S RANGE 35-E NMPM.</p>		<p>9. Well No. 3</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3762 DF</p>		<p>10. Field and Pool, or Wildcat Pearl Queen</p>
		<p>12. County Lea</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Squeeze 50 sacks cement through Baker FA packer at 4800'. Leave cement to FA packer and at least 50' on top.
2. Perforate casing at 1870' and displace 100 sacks cement through holes. Leave 100' cement inside casing.
3. Spot 70 sacks cement 0-170' in annulus and 2-7/8" casing.
4. Erect marker.

24 hr. notice

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>R. R. Suckle</u>	TITLE <u>Production Engineer</u>	DATE <u>2-24-72</u>
APPROVED BY <u>R. R. Suckle</u>	Orig. Signed by <u>Joe D. Ramey</u>	DATE <u>FEB 28 1972</u>
CONDITIONS OF APPROVAL, IF ANY:	TITLE <u>Dist. I, Supv.</u>	

RECEIVED

FLOO 100

1 OIL : ROSEN, STEW. CUMM.
HOLLS, N. M.

100 100
100 100
100 100