

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-5837
7. Lease Name or Unit Agreement Name Northeast Pearl Queen
8. Well No. 18
9. Pool name or Wildcat Pearl Queen
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3767 KB

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☐ OTHER Water Injection Well

2. Name of Operator  
Tamarack Petroleum Co., Inc.

3. Address of Operator  
500 W. Texas, Suite 1485, Midland, Texas 79701

4. Well Location  
Unit Letter L : 2310 Feet From The south Line and 330 Feet From The west Line  
Section 23 Township 19-S Range 35-E NMPM County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and Rig up plugging unit on/or about June 15, 1989.
2. Pull out of hole with tubing and packer.
3. Set CIBP @ + 4800' (perfs 4950-4952, 4967-4970, 5034-5041) Pump 5 sks cement on plug and fill casing with 9.5# mud.
4. Cut 4 1/2" casing + 3200' (B/salt 3140 and pull out and lay down).
5. Pump 200' cement plug 3130 to 2930, tag plug.
6. Pump 200' cement plug 1860 to 1660 (T/anhydrite 1760).
7. Pump 100' cement plug 180 to 80 (B/8 5/8" casing 132'), tag plug.
8. Set 10 sks cement surface plug and marker.
9. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Harold Green TITLE Production Superintendent DATE 4.10/89

TYPE OR PRINT NAME Harold Green

TELEPHONE NO. 915-683-5474

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT I SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE C-103  
TO BE APPROVED.

APR 12 1989