

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

U.S. CONSERVATION DIVISIC  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Salt Water Disposal	7. Unit Agreement Name
2. Name of Operator Big "6" Drilling Company	8. Farm or Lease Name Ora Jackson "A"
3. Address of Operator c/o Oil Reports & Gas Services, Inc., Box 755, Hobbs, NM 88241	9. Well No. 1
4. Location of Well UNIT LETTER <u>M</u> , <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>5</u> TOWNSHIP <u>19S</u> RANGE <u>35E</u> N.M.P.M.	10. Field and Pool, or Wildcat Scharb Bone Spring
15. Elevation (Show whether DF, RT, GR, etc.) 3872 GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug & abandon as follows:

1. Pill tubing & packer & clean up 4 1/2" casing
2. Cut & pull 4 1/2" casing from approximately 4200
3. Spot 100' cement plug across 4 1/2" stub
4. Spot 100' cement plug across 8 5/8" casing shoe at 3989
5. Spot 100' cement plug at 3500
6. Perf 8 5/8" casing at 1500 with 4 holes & circulate cement to surface
7. Set 10' plug at surface with regulation marker
8. Clean & Level location

SET 100' CEMENT PLUG @ 995 DFTAG OR  
CIBPW/35' of CEM at 9950  
100' PLUG AT 7000 - 205XMIN

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Margaret Walker</u>	TITLE <u>Agent</u>	DATE <u>5-19-87</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY <u>Jerry Sexton</u>	TITLE <u></u>	DATE <u>MAY 22 1987</u>
CONDITIONS OF APPROVAL, IF ANY:		