

COPIES RECEIVED		
DISTRIBUTION		
STATE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-1
Effective 1-1-63

<p>SUNDRY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.</p>		<p>5a. Indicate Type of Lease State <input checked="" type="checkbox"/> For <input type="checkbox"/></p>
<p>OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/></p>		<p>5. State Oil & Gas Lease No.</p>
<p>Name of Operator SHELL OIL COMPANY</p>		<p>7. Unit Agreement Name</p>
<p>Address of Operator P. O. BOX 991, HOUSTON, TX 77001</p>		<p>8. Farm or Lease Name State E</p>
<p>Location of Well UNIT LETTER N 660 FEET FROM THE south LINE AND 1700 FEET FROM THE west LINE, SECTION 31 TOWNSHIP 17S RANGE 35E NMPM.</p>		<p>9. Well No. 2</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3996' Df</p>		<p>10. Field and Pool, or Wildcat Vacuum-Glorietta</p>
		<p>12. County Lea</p>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

<p>NOTICE OF INTENTION TO:</p>		<p>SUBSEQUENT REPORT OF:</p>	
<p>PERFORM REMEDIAL WORK <input type="checkbox"/></p>	<p>PLUG AND ABANDON <input type="checkbox"/></p>	<p>REMEDIAL WORK <input type="checkbox"/></p>	<p>ALTERING CASING <input type="checkbox"/></p>
<p>TEMPORARILY ABANDON <input type="checkbox"/></p>	<p>CHANGE PLANS <input type="checkbox"/></p>	<p>COMMENCE DRILLING OPNS. <input type="checkbox"/></p>	<p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
<p>PULL OR ALTER CASING <input type="checkbox"/></p>	<p>OTHER <input type="checkbox"/> OAP and acidize.</p>	<p>CASING TEST AND CEMENT JOB <input type="checkbox"/></p>	<p>OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Perforate 6063-6223'.
2. Set RBP @6250' & packer @6150'. Acidize 6179-6223' w/3,300 gals 15% NE.
3. Reset RBP @6160' & packer @6030'. Acidize 6063-6134' w/2,200 gals 15% NE.
4. Reset RBP @6050' & packer @5950'. Acidize 5999-6019' w/2600 gals NE.
5. Test and OPT.

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. J. Fore A. J. FORE TITLE SUPERVISOR - REG./PERM. DATE OCT 21 1980

APPROVED BY Jerry Sexton TITLE Dist. L. Supv. DATE 10/21/80
CONDITIONS OF APPROVAL, IF ANY: