

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8581

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Sunray DX Oil Company	8. Farm or Lease Name New Mexico "EE" State
3. Address of Operator P. O. Box 1416 - Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER H , 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 13 TOWNSHIP 17-S RANGE 36-E NMPM.	10. Field and Pool, or Wildcat Midway Abo
15. Elevation (Show whether DF, RT, GR, etc.) 3822 DF	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug and abandon as follows: (San Andres recompletion unsuccessful)

1. Cut off 4-1/2" csg at approx. 2600' and pull csg. (TOC 2620').
2. Lay cmt. plugs as follows: a. 25 sxs over San Andres perfs 6479 - 6509
b. 25 sxs in and out of 4-1/2" csg. stub
3. Place 10 sxs cmt plug at surface and install dry hole marker.
4. Clear location and prepare for inspection.

NOTE: Verbal approval given 4-17-68

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Hastings John Hastings

TITLE District Engineer

DATE April 18, 1968

APPROVED BY [Signature]
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE