

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.

-

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole		7. Unit Agreement Name
2. Name of Operator Southwestern Natural Gas, Inc.		8. Farm or Lease Name Effie Carter, et al
3. Address of Operator 900 Building of the Southwest, Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> , <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>6</u> TOWNSHIP <u>17-S</u> RANGE <u>39-E</u> NMPM.		10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 3686' KDB		12. County Lea

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Spot 50 sack cement plug from 12,600' back to 12,000' in 4 1/2" casing.
- Cut 4 1/2" casing at approximately 12,000' and spot 25 sack plug.
- Spot 25 sack plugs at the following points:  
11,770' (Penn.), 8,590' (Abo), 6600' (Glorieta).
- Spot 75 sack plug from 5030' back to 4930' into 8 5/8" casing.
- Cut 8 5/8" casing at approximately 2800' and spot 25 sack plug.
- Spot 25 sack plug at 13 3/8" casing shoe (435') and 10 sack plug at surface.
- Set marker and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Don C. Bennett

TITLE Operations Manager

DATE 9-22-69

APPROVED BY Joe L. [Signature]

TITLE General Manager

DATE SEP 23 1969

CONDITIONS OF APPROVAL, IF ANY: