Form 3160-5 (June 1990)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

N.M. OIL CONS. COMM	ISSION
P.O. BOX 1980 HOBBS, NEW MEXICO	

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-25457

	6.	If	Indian,	Allottee	Or	Tribe	Name
--	----	----	---------	----------	----	-------	------

Use "APPLICATION FO		
SUBMI	7. If Unit or CA, Agreement Designation	
1. Type of Weil	·	
Oil Gas Other	·	8. Well Name and No.
2. Name of Operator Manzano Oil Corporation		Jewett Federal#1
		9. API Well No.
3. Address and Telephone No. P.O. Box 2107, Roswell, NM	88202-2107 (505) 623-1996	30-025-23661
4. Location of Well (Footage, Sec., T., R., M., or Survey I		10. Field and Pool, or Exploratory Area
660'FSL & 660'FEL	Description)	Querecho Plains BS
Sec 15, T18S, R32E	(1	11. County or Parish, State
100, 1100, 1000		Lea, NM
12. CHECK APPROPRIATE BOX	(s) TO INDICATE NATURE OF NOTICE, RE	EPORT, OR OTHER DATA
TYPE OF SUBMISSION TYPE OF ACTIO		TION
Notice of Intent	X Abandonment	Change of Plans
	Recompletion	New Construction
Subsequent Report	Plugging Back	Non-Routine Fracturing
•	Casing Repair	Water Shut-Off
Final Abandonment Notice	Altering Casing	Conversion to Injection
	Other	
		(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form)
 Describe Proposed or Completed Operations (Clearly state all give subsurface locations and measured and true vertice 	pertinent details, and give pertinent dates, including estimated date of sal depths for all markers and zones pertinent to this work.)*	tarting any proposed work. If well is directionally drilled.
b seems to the manage and due verific	an depute for all markers and zones permient to this work.)	
P&A Procedures:		
1. Set 100' cement plug fro	om 8200' to 8100'.	
2. Set 100' cement plug fro	om 6190' to 6090'	
3. Set 100' cement plug acc	coss = 8 - 8/9 shoot $solar and solar and s$	A. a.b.a.c.

Set 100' cement plug across 8-5/8" shoe. 50' below and 50' above.

Shoot off 5-1/2" csg and pull.

Set 100' cement plug across 5-1/2" stub. 50' in and 50' out. Wait on cement. Tag.

Set 100' cement plug at 13-3/8" shoe. 50' below and 50' above. Wait on cement. Tag.

Set 10 sks surface plug. Install DHM.

Verbally approved by Joe Lara 7/18/95. Call BLM @ 393-3612 - 24 hrs prior to beginning P&A procedures.

Signed Allesan Alemande Title	Engineering Technician	Date _	7/17/95
(This space for Fed (ORIG. SED.) JOE G. LARA Approved by Title Conditions of approval, if any: See attached.	PETROLEUM ENGINEER	Date	7/28/95

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.