

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B-1722-1</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>TEXACO Inc.</b>		8. Farm or Lease Name <b>New Mexico "N" St.</b>
3. Address of Operator <b>Box 728 Hobbs, New Mexico 88240</b>		9. Well No. <b>9</b>
4. Location of Well UNIT LETTER <b>D</b> , <b>980</b> FEET FROM THE <b>North</b> LINE AND <b>913</b> FEET FROM THE <b>West</b> LINE, SECTION <b>30</b> , TOWNSHIP <b>175</b> , RANGE <b>35E</b> NMPM.		10. Field and Pool, or Wildcat <b>Vacuum Glorieta</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3992' GR</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Run tbq load w/ mud (25 sx gel per 100 bbls. wtr.).
2. Spot 100' (10 sx) cmt. plug across perfs 6094-6165'. Pull tbq.
3. Run free pt indicator, cut csg. & pull same.
4. Run tbq & spot 100' (35 sx) cmt plug across interval where csg was cut. Pull tbq up & spot 100' (35 sx) plug across 8 5/8" csg shoe @ 1650:
5. Pull tbq to surface & spot 100' (35 sx) cmt plug. Install marker & clean location.

25 SXS

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. Dist. Supt. DATE July 23, 74

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: