

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.
--

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry P&A	7. Unit Agreement Name --
2. Name of Operator Pubco Petroleum Corporation	8. Farm or Lease Name Shipp
3. Address of Operator P. O. Box 869, Albuquerque, New Mexico 87103	9. Well No. 3
4. Location of Well UNIT LETTER F 2130 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 17S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Humble City Strawn
15. Elevation (Show whether DF, RT, GR, etc.) 3757' KB, 3745' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to pull 9-5/8" 36# K-55 casing and P&A starting 1/29/73 in accordance with verbal instructions from Mr. Clements as follows:

1. Cut and pull 9-5/8" casing.
2. Spot 100' cement plug across top of 9-5/8" stub.
3. If top of salt section (2280') is exposed, spot 150 sx. cement 2230-2330'.
4. Spot 90 sx. cement across 13-3/8" shoe 365-465'.
5. Place 8 sx., 10' plug in top of 13-3/8" casing with regulation pipe marker.
6. Hole will be left full of gel mud between cement plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles W. Sanders TITLE Area Production Manager DATE 1/29/73
APPROVED BY John W. Runyan TITLE Geologist DATE FEB 2 1973
CONDITIONS OF APPROVAL, IF ANY: