

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG-498	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator J.C. WILLIAMSON		8. Farm or Lease Name TRAINER STATE	
3. Address of Operator P.O. BOX 16 MIDLAND, TEXAS 79702		9. Well No. 1	
4. Location of Well UNIT LETTER F, 1650 FEET FROM THE WEST LINE AND 2310 FEET FROM THE NORTH LINE, SECTION 25 TOWNSHIP 17-S RANGE 36-E N.M.P.M.		10. Field and Pool, or Wildcat SPENCER(PADDOCK)	
15. Elevation (Show whether DF, RT, GR, etc.) 3825' KB		12. County LEA	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Plugging procedure:

1. Set cast iron bridge plug above top perforations, 6350'. Cut off 4-1/2" casing at top of cement at 5000'.
2. Set 100' plug in and out of 4-1/2" casing stub.
3. Set 100' plug in and out of 8-5/8" stub. (8-5/8" set @ 4713').
4. Set 100' plug in and out of 12-3/4" surface pipe @ 310'. Set a 10 sx plug in the surface and a dry hole marker set.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jack Griffin TITLE Agent DATE 10/17/86

APPROVED BY Jack Griffin TITLE OIL & GAS INSPECTOR DATE OCT 22 1986

CONDITIONS OF APPROVAL, IF ANY:

C.R.

E

RECEIVED  
OCT 20 1986  
O.C.C.  
HOBBS OFFICE