

1. Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-26763
5. Indicate Type of Lease	STATE ☒ FEE ☐
6. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name	
1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER	Lea State ED (NCT-A)		8. Well No. 4
2. Name of Operator Chevron U.S.A. Inc.		9. Pool name or Wildcat Quail Ridge - Bone Spring	
3. Address of Operator P.O. Box 670, Hobbs, NM 88240			
4. Well Location Unit Letter <u>K</u> : <u>2230</u> Feet From The <u>South</u> Line and <u>2200</u> Feet From The <u>West</u> Line Section <u>16</u> Township <u>19S</u> Range <u>34E</u> NMPM Lea County			
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3774'			

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐		CASING TEST AND CEMENT JOBS ☐	
OTHER: ☐		OTHER: ☐	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to P&A well as follows:

POOH w/production equipment. Set CIBP at $\pm 9475'$ and cap w/35' cmt. Spot abandonment mud f/CIBP to csg leak at 7173-7234. Set CIGR at $\pm 7100'$ and sqz per drlg dept. Leave $\pm 50'$ cmt on CIGR. Displace hole w/abandonment mud. Perf sqz holes at 3265'. Set CIGR at $\pm 3165'$ and sqz per drlg dept. Leave $\pm 50'$ cmt on CIGR. Set 100' cmt plug across top of salt f/1760' to 1860'. Spot 10sx surface plug. Cut off WH, install dry hole marker. Change status to P&A.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. L. Emswiler TITLE Technical Assistant DATE 6-6-89
TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEYMOUR
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

JUN 7 1989