

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. OIL CONS. COMMISSION  
P. BOX 1980  
HOBBS, NEW MEXICO 88240

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

FEB 28 1995

DIST. 6 N.M.

Carlsbad, New Mexico

1. Type of Well  
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator  
Manzano Oil Corporation

3. Address and Telephone No.  
P.O. Box 2107, Roswell, NM 88202-2107

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
330' FSL & 1650' FEL Sec 23, T19S, R34E

5. Lease Designation and Serial No.

NM-57285

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Stivason Fed #2

9. API Well No.

30-025-29150

10. Field and Pool, or Exploratory Area

Pearl Queen

11. County or Parish, State

Lea County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Set 100' cement plug from 4900' back to 4800'.
2. Stretch & shoot off casing at free point.
3. Set 100' cement plug at 5-1/2" csg stub if below 8-5/8" surface csg shoe (50' inside stub and 50' outside stub).
4. Set 100' cement plug at 8-5/8" surface csg shoe (50' below and 50' above).
5. Set 10 sks surface plug.
6. Install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed [Signature] Title VP Engineering & Acquisition Date 2/21/95

(This space for Federal or State office use)

Approved by (ORIG. SGD.) JOE G. LARA Title PETROLEUM ENGINEER Date 4/7/95  
Conditions of approval, if any: See attached. Also tag BPE 6620' + dump 35' amt on top.  
Tag plug @ 4800' & plug @ 5 1/2" csg stub / 8 5/8" csg shoe.

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.