

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLI
(Other instructions
verse side)

7-
re-

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS 10240

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Harvey E. Yates Company

3. ADDRESS OF OPERATOR

P.O. Box 1933, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

Unit B, 330' FNL & 198C' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3836.5' GR.

5. LEASE DESIGNATION AND SERIAL NO.

NM 9018

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Young Deep Unit

8. FARM OR LEASE NAME

9. WELL NO.

19

10. FIELD AND POOL, OR WILDCAT

Undesignated Delaware

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 9, T18S, R32E

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) Plug & Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Data: 8 5/8" 24# to 502' cemented w/250 sxs cmt. Circ to surface
5 1/2" 15.5# to 6165' cemented w/1900 sxs cmt. Circ to surface
CIBP @ 5220' w/top perf @ 5134' presently.

P & A procedure:

- 1) CIBP @ 5100' w/35' cmt on top.
- 2) 100' plug from 3813 to 3713' (top of Queen)
- 3) 100' plug from 1164 to 1064' (top of Rustler)
- 4) 100' plug from 550' to 450' (across shoe interval)
- 5) 50' plug @ surface
- 6) Install dry hole marker.

18. I hereby certify that the foregoing is true and correct.

SIGNED

TITLE

Production Manager/Engineer

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

ADMINISTRATIVE
CARLSBAD RESOURCE AREA

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

RECEIVED
JUN 23 11 28 AM '87
CARLSBAD RESOURCE
AREA HEADQUARTERS