

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-29294
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name VIERSEN
8. Well No. 1
9. Pool name or Wildcat SHIPP STRAWN

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator PENNZOIL EXPLORATION AND PRODUCTION CO.	
3. Address of Operator P.O. DRAWER 1828 - MIDLAND, TX 79702-1828	
4. Well Location Unit Letter I : 2130 Feet From The South Line and 660 Feet From The East Line Section 4 Township 17-S Range 37-E NMPM Lea County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3791' KB, 3772' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

P&A Well Per the Attached Well Bore Diagrams.

- 1.) Set C.I.B.P. w/35' cmt @ 11,080'.
- 2.) Load hole with mud.
- 3.) Set plug 8160-8310' using 25 sacks cmt.
- 4.) Set plug 5793-5943' using 25 sacks cmt.
- 5.) Cut & pull 5 1/2" casing @ 4254'.
- 6.) Set stub/shoe plug 4154'-4304' using 50 sacks cmt. Tag plug.
- 7.) Set plug 1963'-2063' using 35 sacks.
- 8.) Set 10' surface plug and install marker.
- 9.) Clean-up & restore location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Roy R. Johnson TITLE Production Accountant III DATE 5-04-92
TYPE OR PRINT NAME Roy R. Johnson TELEPHONE NO. 915-682-2316

(This space for State Use)

APPROVED BY Paul Kautz TITLE Geologist DATE MAY 11 1992
CONDITIONS OF APPROVAL, IF ANY: