

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-29463
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LC 4233
7. Lease Name or Unit Agreement Name	
AMOCO "14" STATE	
8. Well No.	2
9. Pool name or Wildcat	PEARL QUEEN
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	
3740' GL 3756' KB	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	2. Name of Operator TIERRA EXPLORATION, INC.	8. Well No. 2
3. Address of Operator P.O. BOX 5057, HOBBS, NM 88241	9. Pool name or Wildcat PEARL QUEEN	
4. Well Location Unit Letter P : 355 Feet From The EAST Line and 330 Feet From The SOUTH Line Section 14 Township 19S Range 35E NMPM LEA County		
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3740' GL 3756' KB		

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 4800'±, cap with 35' cement.
2. Take stretch in 5½" 15.5# casing. Shoot off @ free point.
3. Pull and lay down casing. Displace hole with Salt Gel mud.
4. Set plug across 5½" casing stub @ 4000' estimate. 50' in and 50' out.
5. Set 35 sx plug @ 3400-3300.
6. Set 35 sx plug @ 1650-1550, casing shoe @ 1600'.
7. Set 35 sx plug @ 350-250.
8. Set 10 sx plug at surface.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

DATE

TYPE OR PRINT NAME

Joe T. Janica

TELEPHONE NO. (505) 392-2112

(This space for State Use)

ORIGINAL SIGNED BY JERRY NEXTON  
DISTRICT I SUPERVISOR

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

FEB 13 1990

THIS COMMISSION MUST BE FILED WITH THE  
RECORDS PRIOR TO THE START OF  
DRILLING OPERATIONS FOR THE WELL  
TO BE APPROVED