

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
310 Old Santa Fe Trail, Room 206
Santa Fe, New Mexico 87503

WELL API NO. 30-025-31846
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. NA
7. Lease Name or Unit Agreement Name ARCO
8. Well No. 1
9. Pool name or Wildcat WILDCAT

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator RAND OIL & GAS, INC.	
3. Address of Operator 1110 N. BIG SPRING MIDLAND, TX 79701	
4. Well Location Unit Letter 0 : 2271 Feet From The EAST Line and 793 Feet From The SOUTH Line Section 18 Township 17-S Range 39-E NMPM LEA County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3650.6 GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move equipment on location.
2. Set CIBP @ 5600'. If set w/WL use 35' cmt cap. If set w/tbg use 25 sx.
3. Cut 4-1/2" csg @ ±5000'. Set 100' plug (50' in & 50' above stub.
TAG PLUG.
4. Set 25 sx or 100' plug @ ±3000'. NMOC requires plug per 2000' O.H.
5. Set 100' plug (50' below & 50' above 8-5/8" csg seat. TAG PLUG.
6. Set 10 sx plug at surface.
7. Set Dryhole Marker.

PROCEDURE PER PAUL KAUTZ 7-6-94

THE COMPLETION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE O. H. ROUTH TITLE AGENT DATE 7-6-94

TYPE OR PRINT NAME O. H. ROUTH TELEPHONE NO. 915-687-0323

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE JUL 11 1994

CONDITIONS OF APPROVAL, IF ANY:

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR