

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

JUL 28 10 01 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 13788
7. Unit Agreement Name
8. Farm or Lease Name STATE 'B'
9. Well No. 1
10. Field and Pool, or Wildcat EUMONT-OIL
12. County LEA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator PAN AMERICAN PETROLEUM CORPORATION
3. Address of Operator BOX 68, HOBBS, N. M. 88240
4. Location of Well UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>N</u> LINE AND <u>330</u> FEET FROM THE <u>E</u> LINE, SECTION <u>1</u> TOWNSHIP <u>19-S</u> RANGE <u>36-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3742' RDB

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Eumont Zone depleted. Workover possibilities have been exhausted.

Propose to P+ A as follows:

Spot 2504 cement plug across perfs 3930-4000.

Shoot & Pull 5 1/2" casing from approx 2400'.

Spot 2504 Plug In+Out of 5 1/2" stub.

" 2504 @ 1561 (T-Sack)

" 2504 In+Out of 8 7/8" CSA 320'.

" 1004 @ surface & erect P+ A marker.

Make final cleanup & restore ground to contour.

TD-4054'

PRD-4030'

5 1/2" CSA 4054' - 700 SX

8 7/8" CSA 320 - circ.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____

TITLE AREA SUPERINTENDENT

DATE JUL 25 1969

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE Geologist

DATE JUL 29 1969

04 2- NMOCG
John W. Ryan
1-NSW
1-SUSP
1-RRY