NO, OF COPIES RECEIVED		Form C-103	
DISTRIBUTION		Supersedes Old	
SANTA FE	NEW MEXICO OIL CONSERVATION COMMISSION	C-102 and C-103 Effective 1-1-65	
FILE			
U.S.G.S.		5a, Indicate Type of Lease	
	JUL 14 11 58 AH '65	State X Fee	
OPERATOR	JULIT	5. State Oil & Gas Lease No.	
······································		B-244	
DO NOT USE THIS FORM FOUSE "APP			
OIL GAS WELL) OTHER-	7. Unit Agreement Name	
Name of Cperator	8. Farm or Lease Name		
Union Texas Petro	State "A"		
Address of Operator		9. Well No.	
Box 1859 - Midlan	1		
. Location of Well		10. Field and Pool, or Wildcat	
UNIT LETTER E	660 FEET FROM THE West LINE AND 1980 FEET FROM	Monument	
North LINE	SECTION 2 TOWNSHIP 20-S RANGE 36-E NMPM	$\mathbf{\nabla}$	
	NOPM.	×/////////////////////////////////////	
15, Elevation (Show whether DF, RT, GR, etc.)		12. County	
	//////////////////////////////////////		
	/////// 3614' DF	Lea	
	eck Appropriate Box To Indicate Nature of Notice, Report or Ot		
	eck Appropriate Box To Indicate Nature of Notice, Report or Ot	her Data	
	eck Appropriate Box To Indicate Nature of Notice, Report or Ot	her Data	
NOTICE O	Cock Appropriate Box To Indicate Nature of Notice, Report or Ot SUBSEQUENTION TO: SUBSEQUENT	her Data T REPORT OF: ALTERING CASING	
NOTICE O	CCK Appropriate Box To Indicate Nature of Notice, Report or Ot SUBSEQUENT PLUG AND ABANDON X REMEDIAL WORK	her Data T REPORT OF:	
	CCK Appropriate Box To Indicate Nature of Notice, Report or Ot SUBSEQUENT PLUG AND ABANDON X REMEDIAL WORK COMMENCE DRILLING OPHS.	her Data T REPORT OF: ALTERING CASING	

The perforations in the subject well from 3820 to 3836' were squeezed 8-23-63 and the well temporarily abandoned. The State "A" No. 1 was completed open hole in June 1936 in the San Andres formation from 3795' to 3910'. In an attempt to reduce the high GOR a $4\frac{1}{2}$ " liner was run in February 1959. Attempts were then made to complete from 3869' to 3887', 3849' to 3866', & 3820' to 3836' which were unsuccessful.

Plugging Procedure

After determining free point on 7" casing, will cut and pull same. Spot 25 sx. cement plug in and out of stub of 7" casing. Spot 10 sx. cement plug on top of hole, cap well and install steel marker. Work will start when permit granted.

13. I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
SIGNED KUManing	Assistant Dist. Supt.	DATE July 13, 1965	
CONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE	