

Form 1004-01-15  
November 1983  
Formerly 9-211

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Other instruction  
reverse side)

Budget Bureau No. 1004-01-15  
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME Reed Sanderson Unit
2. NAME OF OPERATOR Conoco Inc.	8. FARM OR LEASE NAME Reed Sanderson
3. ADDRESS OF OPERATOR P.O. Box 460 - Hobbs, NM 88240	9. WELL NO. No. 21
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below) At surface  1980' FNL & 1980' FWL	10. FIELD AND POOL, OR WILDCAT Eumont Yates 7 Rivers Quee
14. PERMIT NO. 30-025-04199	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 10, T20S, R36E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3604' DF	12. COUNTY OR PARISH Lea
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

1. MIRU. PU and TIH w/4-3/4" bit, 5-1/2" casing scraper and 2-7/8" workstring to 3816'.
2. Set CIBP @ 3785'. Spot 25 sx cement on CIBP.  
\* -> spot ±50' @ ±1430'. SSS
3. Perf 5-1/2" prod. casing @ 363'. Pump 105 sx cement to fill up 8-5/8" x 5-1/2" annulus and set surface plug in 5-1/2" casing.
4. ND BOP and cut off all casing strings at the base of the cellar. Fill the casing strings from the cement plug to surface with cement.
5. Erect a permanent abandonment marker.

For further technical information contact Tom Boelens at 397-5870.

18. I hereby certify that the foregoing is true and correct

SIGNED W.W. Baker W.W. Baker

TITLE Administrative Supervisor

DATE July 11, 1989

(This space for Federal or State office use)

APPROVED BY Shannon Shaw  
CONDITIONS OF APPROVAL, IF ANY:

For: CHIEF, BLM  
TITLE

DATE 7-31-89

\*See Instructions on Reverse Side