

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well  gas well  other

2. NAME OF OPERATOR  
Tenneco Oil Company

3. ADDRESS OF OPERATOR  
6800 Park Ten Blvd., San Antonio, Tx. 78213

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1650 FNL & 990 FWL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input checked="" type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON* (other)	<input type="checkbox"/>		<input type="checkbox"/>

5. LEASE  
NM-07966

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Bay Federal

9. WELL NO.  
4

10. FIELD OR WILDCAT NAME  
Eumont Yates 7-R Queen

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 35 T20S, R36E

12. COUNTY OR PARISH  
Lea

13. STATE  
NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
3565'

RECEIVED  
(NOTE: Report results of multiple completion or zone change on Form 9-330.)  
AUG 19 1980

U. S. GEOLOGICAL SURVEY  
HOBBS, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Treat as follows

Spot 250 gals Xylene let soak for 1 hour. Acidize w/2500 gals 15% NE in 2 stages w/600# rock salt and binzonic acid flakes mix 50/50 between stages. Recover load water and put back on production.

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Mary Hall TITLE Production Analyst DATE 8/14/80

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

No new surface disturbance approved.

\*See Instructions on Reverse Side

APPROVED  
AUG 20 1980  
DISTRICT SUPERVISOR