

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

3 - NMOCC
1 - MIDLAND
1 - FILE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
9. Well No.	
10. Field and Pool, or Wildcat	
12. County	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
GETTY OIL COMPANY

3. Address of Operator
P. O. BOX 249, HOBBES, NEW MEXICO 88240

4. Location of Well
UNIT LETTER **E**, **1980** FEET FROM THE **N** LINE AND **560** FEET FROM THE **WEST** LINE, SECTION **17** TOWNSHIP **19** RANGE **37** NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3717 D.F.

16. **GRAYBURG-SAN ANDRES**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>
	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug and abandon well as follows:

1. Set CIBP @ 3250'.
2. Dump 35' cement on top of CIBP.
3. Circulate hole with 9.2% Brine mixed with 25 sks./100 bbl. salt gel.
4. Lay 100' cement plug w/top @ 1200'. (Top of salt @ 1250').
5. Place 10 sack plug @ surface.
6. Set P & A Marker and Clean Location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL BY: **C. L. Wade** TITLE **AREA SUPERINTENDENT** DATE **NOVEMBER 12, 1975**

PROVED BY: _____ TITLE: _____ DATE: _____

CONDITIONS OF APPROVAL, IF ANY:

1-WLG/bk

RECEIVED

DEC 4 1975

OIL CONSERVATION COMM.
HONOLULU, H. I.