

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
RECEIVED

SUBMIT IN TRIP
(Other instruction
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	2. NAME OF OPERATOR Conoco Inc.	3. ADDRESS OF OPERATOR P.O. Box 460 - Hobbs, New Mexico 88240	4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FSL & 660' FWL - Unit Letter M	5. LEASE DESIGNATION AND SERIAL NO. LC-031621A	6. IF INDIAN, ALLOTTEE OR TRIBE NAME	7. UNIT AGREEMENT NAME	8. FARM OR LEASE NAME Brith A-6	9. WELL NO. 5	10. FIELD AND POOL, OR WILDCAT Monument Blindry	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 6 - T20S - R37E	12. COUNTY OR PARISH Lea	13. STATE NM
14. PERMIT NO. 30-025-05941	15. ELEVATIONS (Show whether DF, RT, GR, etc.)											

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) <u>Clean Out & Acidize</u>	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) MIRR. POCH with rods & pump. Run 0.59 scraper to PBTD.
 - 2) Set pkr at 5600'. Fill backside w/ TFW & pressure test to 500 psi.
 - 3) Acidize w/ 50 bbls 15% HCl acid containing 5% of NALCO's 3452 Acid-Mate chemical and divert w/ a total of 150# rock salt in 2 different stages.
 - 4) Swab well.
 - 5) Release pkr & POOH. Run producing equipment & return well to production.
- For further information contact Tom Boelens at 397-5870.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]

TITLE Administrative Supervisor

DATE January 10, 1989

(This space for Federal or State office use)

APPROVED BY [Signature]

TITLE

DATE 1-27-89

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side