

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	For <input type="checkbox"/>
5. State Oil & Gas Lease No. LG-3605	

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
<p>OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/></p>		7. Unit Agreement Name
<p>1. Name of Operator Lynx Petroleum Consultants, Inc.</p>		8. Farm or Lease Name Humble "A0" State
<p>2. Address of Operator P.O. Box 1666 - Hobbs, NM 88240</p>		9. Well No. #2
<p>3. Location of Well UNIT LETTER <u>N</u> <u>660'</u> FEET FROM THE <u>South</u> LINE AND <u>1920'</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>19S</u> RANGE <u>36E</u> NMPM.</p>		10. Field and Pool, or Wildcat Monument Abo
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3748' GR</p>		12. County Lea

<p align="center">16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to Plug and Abandon as follows:

1. Fill hole with mud-laden fluid.
2. Set CIBP at 6255' and spot 5 sxs cement on top of CIBP.
3. Cut and pull 5½" casing at 5500'.
4. Spot 50 sxs cement from 5600' to 5400'.
5. Spot 30 sxs cement from 5000' to 4900'.
6. Spot 30 sxs cement from 4500' to 4400'.
7. Spot 80 sxs cement from 4250' to 3900'.
8. Spot 30 sxs cement from 3477' to 3277'.
9. Spot 10 sxs cement at surface.
10. Install dry hole marker and clean location.

<p>18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.</p>			
SIGNED <u>Marc Atine</u>	TITLE <u>President</u>	DATE <u>7/28/83</u>	
<p>APPROVED BY <u>ORIGINAL SIGNED BY JERRY SEXTON</u> <u>DISTRICT 1 SUPERVISOR</u></p>		<p>DATE <u>JUL 29 1983</u></p>	
<p>CONDITIONS OF APPROVAL, IF ANY:</p>			

RECEIVED
JUL 28 1983
D.C.
HOBBS OFFICE