

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN DUPLICATE
(Other instructions on reverse side)

ATB*

COPY TO O. C. C.

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

10-875-157 (5)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER <u>DRY WELL</u>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR <u>CONTINENTAL OIL COMPANY</u>		8. FARM OR LEASE NAME <u>SANDERSON B-1</u>	
3. ADDRESS OF OPERATOR <u>Box 460 Hobbs, New Mexico 88240</u>		9. WELL NO. <u>9</u>	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <u>660' FSL & 1980' FEL, Sec. 10-205-36E</u> <u>LEA COUNTY, NEW MEXICO</u>		10. FIELD AND POOL, OR WILDCAT <u>UNDESIGNATED</u>	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) <u>3581 DF</u>	
		12. COUNTY OR PARISH <u>LEA</u>	
		13. STATE <u>N.M.</u>	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETION ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

PROPOSED PROCEDURE TO P+A:

1. FILL 7 7/8" CSG. WITH 10# MUD TO APPROXIMATELY 2550'
 2. CUT AND PULL 7 7/8" CSG. FROM APPX. 2500'
 3. SPOT 50 SX. CLASS C CMT. PLUG IN AND OUT OF 7 7/8" CSG STUB.
 4. FILL WELL BORE WITH 10# MUD TO APPX. 475.
 5. SPOT 50 SX. CMT. PLUG IN AND OUT OF 10 3/4" SURFACE CASING.
 6. FILL 10 3/4" CSG. WITH 10# MUD TO APPX. 18' AND SPOT 10 SX CMT. PLUG TO SURFACE.
 7. INSTALL DRY HOLE MARKER AND CLEAR LOCATION. DRY HOLE MARKER TO READ AS FOLLOWS: SANDERSON B-1 NO. 9-0-10-20-36.
- Accountant: Place 35 cork cement plug in interval 100-100 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

ADMIN. SUPERVISOR

DATE

JULY 27, 1971

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
AUG 6 1971
ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

11565-5 FILE NMFL-4

RECEIVED

AUG 1 1971

**OIL CONSERVATION COMM.
HOBBS, N. M.**