

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-20517
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	B-1626
7. Lease Name or Unit Agreement Name	State "V"
8. Well No.	5
9. Pool name or Wildcat	Eunice Monument GB/SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator AMERADA HESS CORPORATION
3. Address of Operator POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265	4. Well Location Unit Letter <u>G</u> : <u>1980</u> Feet From The <u>NORTH</u> Line and <u>1830</u> Feet From The <u>EAST</u> Line Section <u>36</u> Township <u>19S</u> Range <u>36E</u> NMPM <u>LEA</u> County <u></u>
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to move in and rig up pulling unit. Cut off P&A marker. TIH with tubing, drill collars and bit. Drill out surface plug, cement and aluminum plug at 670'. Tag cement plug at 3,688'. Perform casing integrity test and evaluate for possible use as a water supply/observation well. If well will not be utilized proceed with Step 3. Drill out cement plug at 3,688'-3,840'. Clean out to 4,200'. TOH with tubing, drill collars and bit. TIH with tubing open ended to 4,200'. Rig up cementers. Mix and pump approximately 150 sacks Class "C" Neat cement. Spot a cement plug from 4,200' to 3,650'. Move up hole with tubing and spot 100' plug from 1,205'-1,105'. Move up hole with tubing and spot 10 sack plug at surface. Rig down cementers. Rig down pulling unit. Erect P&A marker. Clean and clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Sr. Staff Assistant DATE 06-07-95
TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JUN 23 1995

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PRODUCTION FOR THE C-103
BY THE OPERATOR

100-1-100

RECEIVED

JUN 21 1895

OLD HOBBS
OFFICE