

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
P.O. Box 1980
Hobbs, NM 88244

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other Dry Hole

2. Name of Operator

Stevens & Tull, Inc.

3. Address and Telephone No.

P.O. Box 11005, Midland, TX 79702 915/699-1410

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FEL and 4650' FSL
Sec 17, T20S, R36E

5. Lease Designation and Serial No.

NMLC046164-B

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

N/A

8. Well Name and No.

Amerada Federal #3

9. API Well No.

30-025-27132

10. Field and Pool, or Exploratory Area

Wildcat

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☒ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

3/31/96 - Upper Delaware test from 5740' - 5882' yielded 100% sulfa-water
Request permission to Temporarily abandon wellbore.

4/2/97 - Total reentry depth at 7458' - a CIBP was set at 6060' to isolate perforations from 6070' - 6080'. Stevens & Tull, Inc. would like to plug and abandon well by setting CIBP with 10 sx cement on top at 5700' to cover existing perforations - recover 7" casing at 3846' and spot 100' cement plug across cut off 7" casing stub - set 100' cement plugs from 2920' - 3020' and 100' cement plug across casing shoe at 1365' (1315' - 1415') and set 25 sx plug at surface. Plugging set 30 days after BLM approval.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct

Signed

Title

Consulting Engineer

Date

4/2/97

(This space for Federal or State office use)

(ORIG. SGD.) ALEXIS C. SWOBODA

Title

PETROLEUM ENGINEER

Date

APR 17 1997

Approved by
Conditions of approval, if any: